

## PACKET SNIFFING

AIM:-

(write a code using raw socket to implement packet Sniffing.)

Algorithm:-

- (1) Start the program.
- (2) Capture network packets from the Wi-Fi interface.
- (3) For each packet received:
  - (a) Check if it contains an IP layer.
  - (b) Get the source and destination IP Address.
  - (c) Identify the protocol (TCP/UDP) / ICMP.
  - (d) Display the protocol name, and IP Address.
- (4) Repeat Continuously until Stopped.

INPUT:-

```
from Scapy.all import sniff  
from Scapy.layers.inet import IP, TCP, UDP, ICMP  
def packet_callback(packet):  
    if IP in packet:  
        ip_layer = packet[IP]  
        protocol = ip_layer.proto  
        src_ip = ip_layer.src  
        dst_ip = ip_layer.dst  
        # determine the protocol  
        protocol_name = ""  
        if protocol == 1:  
            protocol_name = "ICMP"
```

```
if protocol == 6:  
    protocol_name = "TCP"  
  
elif protocol == 17:  
    protocol_name = "UDP"  
  
else:  
    protocol_name = "Unknown Protocol"  
  
print(f"Protocol: {protocol_name}")  
print(f"Source IP: {src_ip}")  
print(f"Destination IP: {dest_ip}")  
print("n" * 50)
```

```
Sniff(iface='Wi-Fi', prn=packet_callback, filter='ip',  
      store=0)
```

Output:

```
Protocol: TCP  
Source IP: 192.168.1.10  
Destination IP: 172.217.167.78
```

```
Protocol: UDP  
Source IP: 192.168.1.10  
Destination IP: 8.8.8.8
```

```
Protocol: ICMP  
Source IP: 192.168.1.10  
Destination IP: 192.168.1.12
```

Result:

Packet Sniffing using Raw Sockets has  
been successfully implemented.